



Video Products Technical Bulletin 30-2010-139

DATE: **October 18, 2010**

SUBJECT: **MANUAL CORRECTION—ZOOM SPEED CAPABILITY OF LENS PACKED WITH CAMCORDER**

MODEL: **PMW-320K**
PMW-350K
PMW-350K/1
PMW-EX330K

DESCRIPTION

Correct the following manual as shown in Figure 1.

- PMW-320K Operating Instructions*
- PMW-350K Operating Instructions*
- PMW-EX330K Operating Instructions*

SERIAL NO: **ALL**

Italicized information in green applies to customers outside the United States.

101

CHAPTER 6 MENU AND DETAILED SETTINGS
MENU LIST
OPERATION MENU

Menu Items	Sub-item	Settings	Description
≈			
Assignable SW Assigns functions to assignable switches. See "Assigning Functions to Assignable Switches" (page 131) for more information about assigning functions.	<0>	See page 131.	Assigns function to ASSIGN. 0 switch.
	<1>		Assigns function to ASSIGN. 1 switch.
	<2>		Assigns function to ASSIGN. 2 switch.
	<3>		Assigns function to ASSIGN. 3 switch.
	<4>		Assigns function to ASSIGNABLE 4 switch.
	<5>		Assigns function to ASSIGNABLE 5 switch.
	RET		Assigns function to RET button on the lens.
	C. Temp		Assigns function to COLOR TEMP. button.
Zoom Speed	0 to 20 to 99		When Zoom has been assigned to the ASSIGNABLE 4 or 5 switch, specifies the zoom speed.

Note

When using the auto focus lens packed with the camcorder, the guaranteed zoom speed range is 6 to 99.

← ADD

Figure 1

PMWM10-028