

### Major functions updated with V1.25

#### CBK-DCB01 Demand Converter Box

Focus/zoom operation from commercially available focus demand/zoom demand devices is available through the CBKDCB01 Demand Converter Box (optional).

- Supported demand devices  
Canon Focus Demand FR-35 or equivalent, Zoom Demand ZSD-15M II  
FUJIFILM Focus Demand EPD-21A-A01, Zoom Demand ERD-20A-A02
- Recording start/stop is also possible with the REC switch on the demand device connected to the CBK-DCB01.
- Sony RM-B170 or RM-B750 Remote Control Unit can be connected to the CBK-DCB01.

#### Restrictions

- When the CBK-DCB01 is connected to the camcorder, the operation of the PUSH AF button and FOCUS AUTO/MANUAL switch on the supplied VCL-614B2X zoom lens is not possible.
- In addition to the above restriction, the following controls on the camcorder become inoperative when a remote control unit is connected to the CBK-DCB01: GAIN switch, WHITE BAL switch, WHT BAL button, SHUTTER switch and BARS/CAM button.
- For details, refer to the Operating Instructions supplied with the CBK-DCB01.

### Major functions updated with V1.20

#### Usable media

XQD memory card series added (with XQD ExpressCard Adapter QDA-EX1)

#### Restrictions

- For restoration of media recorded with this unit, be sure to use this unit. Media recorded with a device other than this unit or with another unit of different version (even of the same model) may not be restored using this unit.
- High-speed playback may not be properly achieved.
- Slow Motion recording by the Slow & Quick Motion recording function cannot be made.
- Not all XQD memory cards are guaranteed to work with this camcorder. For compatible memory cards, contact your Sony dealer.

#### RM-B170

The unit supports the remote control unit RM-B170.

### Major functions updated with V1.18

#### Timecode

Ensure timecode continuity in 720P mode, even when the signal processing load is high.

### Major functions updated with V1.17

#### Timecode

Ensure timecode continuity when the HDCA-702 is connected to this unit and the timecode run mode is set to Rec Run in 720P mode.

#### Media

Enable this unit to format an SxS memory card having all data deleted by "Disk Utility" function of Macintosh.

## Major functions updated with V1.16

### RCP-1000 series

Support the remote control panels RCP-1000/1001/1500/1501/1530.

### RM-B150

Allow the lens diaphragm to be closed from the RM-B150 Remote Control Unit.

### Media

Improve the reliability of error processing for errors that occur during recording to SxS memory cards.

## Major functions updated with V1.15

### Usable media

Support “New SxS-1 (SBS-32G1A/64G1A)” with improved data read speed.

## Major functions updated with V1.10

### Usable media

- SxS-1-series memory card added
- “Memory Stick PRO-HG Duo HX” added (with the optional MEAD-MS01 Media Adaptor)
- SDHC card added (with the optional MEAD-SD01 Media Adaptor)

### Menu

- Version information available on the OTHERS menu

### Restrictions

- For restoration of media recorded with this unit, be sure to use this unit. Media recorded with a device other than this unit or with another unit of different version (even of the same model) may not be restored using this unit.
- High-speed playback may not be properly achieved with a Media Adaptor.
- Slow Motion recording by the Slow & Quick Motion recording function cannot be made with a Media Adaptor.