

Recording an External Video Signal (Analog Line-In, HDV/DV In)

You can record on the tape an external video signal, either from the analog video input (SD standard) or from the HDV/DV input (SD or HD standard).



Analog Line-In

1. **Connect the camcorder to the analog video device.**
For the connection diagram to an analog device refer to Section [4](#) of *Connecting to a Monitor/TV* (□ 99).
2. Set the **POWER** dial to **VCR/PLAY** and load a blank cassette.
3. Open the menu and select **[AUDIO SETUP]**. Select **[DV AUDIO]**, select a setting option and close the menu.
4. **Connected device: Load the recorded cassette.**
5. Press the **●** and **||** buttons (or the **REC PAUSE** button on the wireless controller).
 - The camcorder enters the record pause mode. In this mode you can monitor the picture on the screen.
 - If you press only the **●** button, recording will start immediately.
6. **Connected device: Play back the tape.**
7. Press the **||** button (or the **PAUSE ||** button on the wireless controller) when the scene you wish to record appears.
Recording starts.
8. Press the **■** button to stop recording.
9. **Connected device: Stop playback.**