

## Settings Table

1	Settings	<b>A7 IV</b>	<b>AX700</b>
2			
3	SETTINGS		
4	Custom 1		
5	Custom 2		
6	Custom 3		
7	Custom 4		
8	Wheel		
9			
10			
11	File Format	XAVC HS 4k	
12	Movie Settings	24p / 100M 4:2:0 8bit	24p / 4:2:0 8bit
13	S&Q Settings	24p / 1fps / 100M 4:2:2 10bit	
14	APS-C S35 Shooting	off	n/a
15	Lens Compensation	Auto / Auto / Auto / On	
16	Shooting Mode	Flexible Exp. Mode	
17	Audio Recording		
18	Audio Recording (or 6 with microphone)	Live / Off / On	
19	Image Stabilization	Active / Auto / Auto	
20	Shooting Display	On	
21	Shooting Display Rule of 3rds Grid	On ?	Off
22	Marker Display	Off / Off	
23	4:3	Off / Off	
24	Exposure	On	
25	Metering - Multi	On / Center	
26	White Balance	- C.Temp./Filter / Standard / 3 (slow)	
27	Color/Tone	Off / - / PP8 / Off	
28	Zebra	Off / Custom 1 - 75 +-5	

1	Settings	<b>A7 IV</b>	<b>AX700</b>
29	AF/MF	AF-C / 3 / 4 / off	
30	Focus Area	- Zone or Center / Red / does not circulate / standard	
31	Face/Eye AF	- On / Human / All on / Auto / on / on	
32	Peaking Display	- On / Mid / Yellow	
33			
34	MOVIE CUSTOM KEY/DIAL SETTINGS		
35	Rear 1		
36	1- Gamma Disp. Asssist Sel.		
37	2- Focus Magnifier		
38	3- ISO Auto Manual Set		
39	4- ASPC S35 / Full Frame		
40	5- Zebra Display Select		
41	Rear2		
42	1- Audio Rec Level		
43	2- Steadshot		
44	3- White Balance		
45	4- Marker Disp. Sel.		
46	5- Peaking Display Select		
47			
48	Top		
49	1- Movie Shooting		
50	2- AV Auto/Manual Switch		
51			
52	Lens		
53	1- AF/MF Selector Hold		

1	Settings	<b>A7 IV</b>	<b>AX700</b>
54			
55	Dial/Wheel		
56	1-Av		
57	2-ISO		
58	3-Tv		
59	4- NOT SET		
60			
61	FUNCTION BUTTON SETUP		
62	TOP - LEFT TO RIGHT	Rec Frame Rate - Record Setting - Focus Area - Picture Profile - Metering Mode - Exposure Compensation	
63			
64	BOTTOM - LEFT TO RIGHT	Peaking Level - Zebra Level - Focus Mode - Focus Map - Rec. Media Settings	
65			
66	TIMESTAMPS		
67			